

RADIATION ALERT™

Monitor 1000^{EC}

yx



The Monitor 1000^{EC} measures gamma, and x-rays. Perfect for most applications requiring an energy compensated detector. Users can choose from readings of CPM, CPS, $\mu\text{Sv/hr}$, mR/hr , or in accumulated counts. It has a red count light, a beeper that sounds with each count detected, and includes an adjustable timer, and selectable alert. The free Observer USB Software allows you to set alarms, select preferences, and download your collected data. The Bluetooth and Observer BLE App enables saving, sharing, and automation of surveys and RadResponder compatibility.

Detector

Energy Compensated Halogen-quenched GM tube.

Operating Range

mR/hr - .001 ($1\mu\text{R}$) to 1000 mR/hr

$\mu\text{Sv/hr}$ - .01 to 10000

CPM - 0 to 450,000

CPS - 0 to 7500

Timed Count - 1 to 9,999K (9,999,000) counts

Accuracy

Typically $\pm 15\%$ of reading. $\pm 10\%$ typical (NIST)

Alert Set Range

mR/hr .001 - 1000 and CPM 1 - 450,000

Internally mounted beeper. 70db @ 1m.

(Can be switched off for silent operation.)

Count Light

Red LED flashes with each count.

Outputs

USB and Bluetooth 4.1 for use with included Observer Software and Apps (RadResponder Ready)

Size

140 X 68 X 33 mm (5.5 X 2.7 X 1.3 in.)

Energy Sensitivity

450 CPM/ mR/hr referenced to Cs^{137}


- Detects gamma and x-rays down to 40 keV.
- Response is flat from 40 keV up.

Display

Backlit Graphic LCD

Audio Indicator

Sounds with each count (can be switched off for silent operation)



SE INTERNATIONAL, INC.



P.O. Box 39, 436 Farm Rd. Summertown, TN 38483

1-800-293-5759

Fax: 1-931-964-3564

www.seintl.com

radiationinfo@seintl.com



RADIATION A•L•E•R•T

RADIATION ALERT™ Monitor 1000^{EC}

Anti-Saturation

Readout will hold at full scale in radiation fields as high as 100 times the maximum reading.

Power Requirements

USB or 2 AA alkaline batteries. Approx. 800 hrs @ background.

Includes


Carrying Case, Xtreme Boot, Stand, Mini-USB Cable, Lanyard, Certificate of Conformance, Observer USB for PCs and Observer BLE for Android Download

Options

NIST Calibration

Limited Warranty

1 year limited warranty



USB Observer Software collects data stored in the internal memory of The Monitor 1000^{EC}



SE INTERNATIONAL, INC.



P.O. Box 39, 436 Farm Rd. Summertown, TN 38483

1-800-293-5759

Fax: 1-931-964-3564

www.seintl.com

radiationinfo@seintl.com



RADIATION
A • L • E • R • T